

PA20-20-1Psw Data Sheet

20 pin PLCC Auto-eject *Dead-Bug* socket/20 pin DIP 0.3" or 0.6" plug

or

20 pin PLCC Lidded ZIF *Live-Bug* socket/20 pin DIP 0.3" or 0.6" plug

Supported Device/Footprints

These adapters allow programming of many PLCC and CLCC devices in their DIP footprint. The following is a partial list.

The following devices are supported using the indicated footprint.
Generic: 10H8, 10L8, 12H6, 12L6, 14H4, 14L6, 14H4, 14L4, 16C1, 16H2, 16L2, 16L8, 16N8, 16P8F, 16R4, 16R6, 16R8, 16RA8, 16RP4, 16RP6, 16RP8, 16V8, 16X4, 18N8, 18P8, 20L8, 20R8, PLS 155, PLS 157, PLS 159

Footprint: Same device 20DIP 0.6" or Same device 20DIP 0.3"

Adapter Construction

The following chart identifies all the versions of this adapter currently available and the correct placement of the device to be programmed. For more information see the drawings at left.

Adapter	Plug	Socket Style	Device Placement
PA20-20-1PD3	0.3"	Auto-eject	Pins up
PA20-20-1PD6	0.6"	Auto-eject	Pins up
PA20-20-1PZ3	0.3"	Lidded ZIF	Pins down
PA20-20-1PZ6	0.6"	Lidded ZIF	Pins down

The following chart identifies the various boards and sockets that make up these versions of the adapter

Adapter	Socket	Circuit Board
PA20-20-1PD3	20-205	20-1PD3
PA20-20-1PZ3	20-602	20-1PZ3
PA20-20-1PD6	20-205	20-1PD6
PA20-20-1PZ6	20-602	20-1PZ6

Test Sockets

LSC #	Style	Mfgr/Pn
20-205	Auto-Eject	Yamaichi IC 120-0204-205
20-602	Lidded ZIF	Yamaichi IC 51-0204-602


The adapter is made up of 2 sub-assemblies. They assemble via connectors making the adapter modular. This way the sub-assemblies can be easily replaced.

When disassembling the adapter take care not to bend the pins. When reassembling the adapter note the pin 1 indicators to align the parts correctly.

Adapter Wiring


The adapter is wired 1 to 1. The following chart shows the connections from the PLCC device to the adapter's DIP plug.

DEVICE	PLUG
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20



PA20-20-1PD6

**NOTE: THIS IS A DEAD-BUG SOCKET
THE PLCC DEVICE IS INSERTED UPSIDE-DOWN**



PA20-20-1PZ6

**NOTE: THIS IS A LIVE-BUG SOCKET
THE PLCC DEVICE IS INSERTED RIGHT-SIDE-UP**



2173 Salk Ave
Carlsbad, CA 92008



www.adapt-plus.com
sales@adapt-plus.com



P:209 839 0200
F:209 839 0235

Rev 09/09/99

Page 1 of 1